

### **Inflatable Rules:**

Generally speaking, no food or drink, no shoes, no sharp objects, no visible metal zippers, no medical conditions including pregnancy, no wresting/roughhousing, no hanging on the netting, and no flips. Adhere to these rules. Injuries or accidents are very rare, but generally they are the result of a lack of supervision or inappropriate use.

### **Absolutely NO**

Food	Drinks	Shoes
Candy	Eyewear	Silly String
Flips	Jewelry	Wrestling/Rough Housing
Climbing or hanging From the interior of the unit	Bouncing off the inflatable walls	Sitting or laying down while others or bouncing

### Operating Procedures:

Each operator is responsible for reading and understanding the following instructions.

1. Participants may not wear their shoes.
2. NO food, drink, or gum, canned spray string (Silly String), loose or sharp objects including eyeglasses or loose fitting jewelry.
3. The rated capacity should never be exceeded. The MAXIMUM capacity of the inflatable is as noted on each inflatables procedures.
4. The attendant should assist the participants when they enter and exit the inflatable.
5. The attendant should position himself/herself close to the entrance of the inflatable activity where they may control access and within view of the occupants.
6. When the inflatable is in use, the attendant/host should watch the occupants at all times and activities such as wrestling, climbing walls, horseplay and flips are not to be allowed. Participants engaging in those activities must be removed from the inflatable. It is important that attendants realize they control the operation of the inflatable and that removing participants who do not obey the rules is a safety measure design to protect ALL participants.
7. It is the duty of the attendant to enforce all written and posted safety procedures and operation procedures posted on the inflatable activity they are operating.
8. The attendant must never leave the inflatable unattended at any time. If the attendant needs relieved, the attendant must request a back- up with an activities committee member or the inflatable is required to be deflated and power removed from the unit.
9. All participants are required to wear all protective equipment provided to include but not limited to head gear, safety harnesses, gloves, etc.

### Emergency Procedures:

Emergencies may be caused by weather, equipment failure, power failure and from actions of the participants. Here are some examples of how to handle some various situations should they arise.

### Power Failure:

With an interruption of power the unit will start to deflate. Perform the following.

1. Stay calm and have the participants exit the inflatable immediately.
2. Notify an activities committee member.
3. Check the blower switch, the blower plug and extension cord if used. Make sure all connections are made. Check the fuse/circuit breaker panel.
4. If no power still exists, it may be a blower malfunction. Call a representative immediately. Unplug the blower from its power source.

### Damage:

Should the inflatable become damaged while in operation, perform the following.

1. If the unit ripped or punctured and begins to deflate, calmly have all participants exit immediately and turn the blower(s) off.
2. Note exactly what happened, how many participants were on/in the unit and any unusual circumstances.
3. Contact an activities committee member immediately.